

Anti Lock Brake System ■

Traction Control System ■

5Mode Aux Ch Systems ■



4Channel ■

P R E S T O

Operation manual

**SUPER STEERING
FM PROPORTIONAL
SYSTEM**

Auto Display ■

Steering Speed ■

⚠ Caution

- Be sure to read this manual carefully before use this unit.
- In order to make use of this manual anytime, please keep it carefully.

Direct Travel Set ■

KO PROPO®
DIGITAL PROPORTIONAL SYSTEM

3Model Memorys ■

• • • • •

The auxiliary channels of this unit (ch3,4) can not be used with the included 2ch receiver (KR297).
It is necessary to purchase an additional channel adapter (optional).

It is illegal to reproduce the contents of this manual without permission. Although every effort has been made to ensure the accuracy of the information contained in this manual, please contact us if you have any questions or if you find any errors.

We cannot assume any responsibility for any damage arising from the use of this product by the customer.

The contents of this manual are subject to future change without notice.

Contents

Reference Page

Read First	How to Use this Manual 1 (How to Find Information in This Manual)
	Notes on Safe Usage 3-5 (For the Safe Usage of this Unit)
	Names and Usage of the Parts of the Transmitter 6-12 (Names of Parts and Usage of Each Part of the Transmitter)
Preparations	Inserting Dry Cells 7 (Battery Box)
	Inserting a Nica d Battery and Charging 7,8 (Charge Jack)
	Changing the Frequency 8,30 (Changing The Crystals)
	Adjusting Neutral Position of Steering and Throttle 10 (How to Use Trim)
Operation	Adjusting the LCD Contrast 8 (LCD Contrast)
	Simple Adjustment of Servo Angle 12 (Direct Set Function)
	Changing the Model Memory 14 (Model Select)
	Adjusting Steering Servo Angle 15 (Steering Travel)
	Adjusting Overall Angle 16 (Steering Travel)
	Left, Right Separate Adjustment 15 (Steering Travel)
	Changing the Steering Response Characteristics 17 (Steering Response)
	Make Steering Characteristics Quicker 17 (Steering Curve)
	Make Steering Characteristics Milder 18 (Steering Speed)
	Adjusting Throttle Servo Angle 19 (Throttle Travel)
	Adjusting High Speed Point 19 (Travel F)
	Adjusting Brake 19,20 (Travel B)
	Changing the Characteristics of Throttle and Brake 21 (Throttle, Response)
	Make Throttle Characteristics Quicker 21 (Throttle Punch)
	Make Throttle Characteristics Milder 22 (TRC)
	Make Brake Characteristics Quicker 23 (Brake Punch)
	Preventing Wheel Locking 24 (ABS)
	Changing the Direction of Servo and ESC 25 (Reverse)
	Changing the Direction of Ch3,4 lever 25 (Reverse)
	Select the Movement Method of Auxiliary CH (ch3,4) 26 (Auxiliary CH Select)
	Set up Auxiliary CH Movement Angle 27 (How to Set up the Auxiliary CH Position)
	Changing the Function of GD Lever 28 (GD Lever Select)
	Changing the Pumping Cycle of ABS Brake 29 (ABS Cycle)
	Input and Delete Name in Model Memory 29 (Model Name)
Receiver	Connecting the Servo or ESC to the Receiver 30 (Connecting the Receiver)
	Preventing Out of Control 31-33 (Notes on Receiver Usage)
Others	Find out Function Names and Things you can do
	From LCD 34-36 (LCD Screen Table)
	Find out the Meaning of LCD 37,34-36 (Index, LCD Screen Table)
	Want to Know Terminology of Radio Control Models 38 (Description)

• • • • •

Explanation of warnings and signs

Failure to observe the matter discussed in such an item poses a possibility of injury or damage to the equipment or property.





Enforcement matter

Must carry out

Be sure to use grommets and be sure that the servo is not touching any metal plates directly.*The vibrations may damage the servo and the model may run out of control.



















Notes Before Installation

Caution









 Caution	 Be careful not to reverse the polarity of the transmitter and the receiver. Reverse polarity could damage the units.
 Caution	 Be sure to use genuine KO Propo products e.g. transmitter, receiver, ESC and other option parts. *We cannot assume any responsibility for the use of other companies products with this unit.

Notes on Driving (Sailing).

Warning





 Warning	 When turning on the power switch, be sure that the frequency band is available.*Other people's models using the same frequency will run out of control.
 Warning	 Do not use this unit in thunderstorms. *There is possibility of lightning striking the antenna.
 Warning	 Do not use the transmitter in the rain or in a location where water might get on it.*The unit may become wet in and run out of control.
 Warning	 Do not run the model in the following places. 1. Near to other radio control car circuits. (within 3km) 2. Near to people or on the road. 3. The surface of the water where actual boats are existence. 4. Near to electric wires, communication facilities. *In the case of the model running out of control, dangerous situations will occur.
 Warning	 Do not run the model when you experience difficulties in concentration through tiredness, alcohol or medication. *The mis-judgement may result in accidents.
 Warning	 Be sure to extend the aerial of the transmitter to full length. *Incorrect signals emitting will cause model run out of control.
 Warning	 Do not allow fuel or exhaust to touch plastic parts. *Doing so causes risk of damage.
 Warning	 Be sure to confirm that the model memory is matched to the models currently running. *Not doing so may cause vehicle to run out of control.
 Warning	 When you make function changes, be sure to stop the engine or disconnect the motor lead wire.

Caution





 Caution	 Always turn on the switch on the transmitter first, followed by the receiver. When turning off the switches, always turn off the receiver first, followed by the transmitter. *If you don't follow the correct order, receiver may get interference and run out of control.
 Caution	 Attach band plate when you operating the unit. *Display your frequency clearly to other people.
 Caution	 Do not touch the engine, motor, ESC where is generated heat is. *May result in burning.
 Caution	 Because the transmitter emits high-frequency energy, do not touch the antenna while the transmitter is in use.

Notes after Driving (Sailing)

Warning







- | | |
|--|--|
|  Warning |  In the case of electric car use, be sure to disconnect the nicad battery afterwards.
*It may cause fire or the model to run out of control in case of switch being left on. |
|  Warning |  When storing the transmitter, batteries and models, be sure to keep them out of the reach of children.
*It may resulting in damage by chemicals. |


Caution







- | | |
|--|--|
|  Caution |  Be sure to disconnect the battery from the transmitter when not in use for a longtime.
*It may damage the transmitter if you leave the battery in the transmitter for a long time. |
|  Caution |  Do not store the transmitter in the following places.
1. Extremely hot or cold places (+40C , -10C).
2. Direct sunshine.
3. High humidity places.
4. Dusty places.
* If you store the unit under these circumstances, it may result in misoperation or damage to the unit. |

Notes on Charging Nicad Battery and Hydropack (sold separately)

Danger

- | | |
|---|--|
|  Danger |  Do not short the battery terminals.
*It is dangerous because it may be the outbreak of fire or explosion . |
|  Danger |  Never incinerate the batteries.
*It is very dangerous because they may explode. |
|  Danger |  Be sure to use KO Propo charger and use the correct charging current.
*Avoid over charging the battery. Over charging not only damages the battery, but can cause excess heat to build-up and possibly cause fire, resulting in serious accidents.
*Do not use the Hydropack with rapid chargers from other companies, because there is a possibility that the auto cut-off function will fail to operate. |

	In the event of liquid leaking from battery, do not allow liquid to touch eyes or skin. Burns and blindness may occur. Apply large amounts of water and contact a doctor immediately for treatment.
---	---

- | | |
|---|--|
|  Danger |  Do not apply big shocks to the batteries. *It may damage the battery and result in short circuits and possibly a fire. |
|  Danger |  Do not dismantle or modify the battery.
*Dismantle the battery may cause liquid to leak out and it is very dangerous. |
|  Danger |  Do not wet batteries and do not charge wet batteries. |


Nicad batteries are recyclable.

Please support recycling.

Names of Parts of the Transmitter

.....

Front side




Back Side

Charging jack (P8)

How to Use the Transmitter

How to Open the Battery Cover

- 1 Press down on the two points indicated by the arrows
- 2 Slide the battery compartment cover off.



How to Insert Dry Cells (sold separately)

1. Insert eight size AA batteries into the battery box.


Caution

Be very careful to load the positive and negative terminal of each battery properly!

- 2 Insert the battery box matched with battery box terminals and transmitter terminals.
- 3 Close the battery compartment with cover.

Caution


Do not use AA size nicad battery. It may cause corrosion inside the transmitter with gas when charging.



How to Insert a Nicad Battery or Hydropack (sold separately)

- 1 Plug in the connector of a nicad battery pack.
- 2 Insert nicad battery or hydropack correctly.
- 3 Close the battery compartment with cover

Be sure not to catch battery lead in between compartment and cover.



How to Use the Transmitter

Charging


Connect AC mains charger or DC 12v charger (KO Propo products) into the Tx charge jack and charge.

! Warning

! In case of nicad batteries being used for transmitter or receiver, be sure to charge properly. If the batteries are not fully charged, the model may run out of control.

! Caution

! Do not charge when using dry cells. If you charge dry cells, it could cause damage the transmitter.




Changing the Crystals (changing the frequencies)

Insert the crystal properly and be careful not to bend the pins.

! Warning

! When changing the crystals, be sure to use genuine FM-type transceiver crystals from KO Propo. Crystals from other manufacturers may operate at slightly different frequencies, resulting in loss of control.




Adjust LCD Contrast

One of the characteristics of a dot matrix LCD is change of contrast depending of the temperature. Adjust the contrast so that the display is easy to see. (4 levels)

① so that the display is easy to see. (4 levels)

② Power switch on. (displayed initial screen)



How to Use the Transmitter


Key Panel

Function Key

Each LCD display (Function) changes in order

Select Key

Changing the LCD display (Function) except for figure data. (i.e. CH)



How to press the key
Press the middle of each keys with finger

Do not use sharp material, it may damage the cover.

+ , - , Key

Changing the LCD display (Function) of figure data. Press both keys at the same time will display default figure. (except for some functions)

Warning display in the LCD

Battery alarm



If the battery voltage drops to 8.7V or less whilst the transmitter is in operation, (Low Batt) will be displayed on the LCD screen. In this event, replace the batteries



Warning



If (Low Batt) sign appears collect the model immediately.
*The radio signals will become weaker, which could cause a loss of control.

Memory Error



The LCD screen shown at left appears if something happens on the CPU and (Memory Error) will be displayed with a alarm.



Warning



If (Memory Error) appears please ask for repair. It may result in misoperation.

How to Use the Transmitter

How to Use Trim Lever (Adjusting the neutral of servo etc)


- 1 When the steering wheel and throttle trigger are both in the neutral position by moving trim left or right (up or down), you are able to adjust the neutral position.
- 2 At the same time the LCD display automatically indicates trim position screen.

(Auto display function)

After the operation, it will revert back to previous screen in approx. 5 seconds.

(does not apply when in System Mode)


Trim position
(Throttle)



Trim position
(Steering)



Steering Trim



- Setting range is R/L 0-80, (F/B 0-80). Make sure that the setting does not lock the linkage and cause excessive force to be applied to the servo.

(In the throttle trim, it does not move at high end. Only the maximum turning of braking will be effective by trim adjustment)



Advice



- During the linkage process, adjust the trim close to '0' position.

How to Use the Transmitter

How to Use the GD Lever

GD lever A and B operates left and right. GD lever C operates up and down.

- ① GD lever A will adjust the steering travel (turning angle). During this operation, LCD display automatically changes to the travel position (does not apply when in System mode), and return to the previous screen display after approx. 5 seconds.
- ② GD lever B will adjust the brake travel (brake turning angle). During this operation, LCD display automatically changes to the brake position (does not apply when in System Mode), and return to the previous screen display after approx 5 seconds.
- ③ GD lever C will operate CH3 feature. During this operation, LCD display automatically changes to the CH3 position (does not apply when in System Mode), and return to the previous screen display after approx. 5 seconds. Please refer to page 27 for setting up each position.



Advice


You can change each lever's function. (GD lever select, P28)

How to Use the Transmitter

Simple Way to Adjust the Turning Angle of the Servo (Direct Set Function)

Steering


- 1 Turn the wheel to the maximum position of left or right and you can adjust the turning angle of each direction by operating the steering trim lever.
- 2 In addition to the trim setting, the LCD display will automatically change to the steering travel function display screen (does not apply when in System Mode), and return to the previous screen display after approx 5 seconds. This setting can range from 0-130.



Operate the trim lever and this setting can range from 0-130.

Throttle

- 1 Move the trigger to the maximum position forward or backward and you can adjust the throttle angle by operating the throttle trim.
- 2 In addition to the trim setting, the LCD display will automatically changes to the throttle travel function forward and brake (F.B) display screen. (does not apply when in System Mode) and return to the previous screen after approx. 5 seconds. This setting can the range from 0-130



Operate the trim lever and this setting can range from 0-130



Advice

When adjusting the turning angle by direct set, release the trim lever and return to neutral position of wheel or trigger. If you release the trim in opposite direction, it may result in an incorrect trim setting.

About LCD Display

Initial Screen

- This Screen is Displayed When the Power is First Turned on.


Model Number (1-3)

Current model number among the three different setting stored in the memory.

Model Name

None stored when unit is released

Battery voltage




Calling Up LCD Screen/LCD Map

- The LCD Screen used on this transmitter is divided into two modes (group). System Mode includes function screens that are used during linkage and that are not used during normal

Enter Function Mode by pressing the function key while in Initial Screen. Then pressing the Function Key in regular sequence will cause screen to change accordingly.

Enter System Mode by pressing and hold Select Key and pressing the Function Key. Then pressing the Function Key in regular sequence will cause the screen to change accordingly.




The Explanation of Each Function (Function Mode)

.....


Changing the Model Memory (Model Select)

- This transmitter can store all settings for up to three cars. This function is used to switch among those settings.
- 1 Press the Function Key two times to switch to Model Memory screen.
 - 2 The model number can be changed by using the (+) and (-) keys.



! Caution

! Be sure to use Model Select and GD Select after you fully understand the functions.
*Incorrect operation may cause car to run out of control.




The Explanation of Each Function (Function Mode)

Adjusting the Turning Angle of the Steering Servo (Steering Travel).

- Be sure to set the Travel Position of G D Lever A at a maximum value before adjusting the linkage.

□ Adjusting by Trim Lever (Direct Set Function)


- 1 Change the LCD display from the Initial Screen to the Function Mode. (refer to P13)
- 2 Turn the steering wheel fully to the right and the LCD automatically displays the right wheel steering turning angle. Adjust angle by pressing the trim lever.
- 3 Turn the steering wheel fully to the left and the LCD automatically displays the left wheel steering turning angle. Adjust angle by pressing the trim lever.



Operate the trim lever and this setting can range from 0-130.

□ Calling up the Screen and Adjusting

- 1 Pressing the Function Key three times from the initial screen it displays the Steering Travel screen.
- 2 Turn the steering wheel all the way to the right then adjust the right side turning angle by pressing the (+) (-) keys. (This setting the range from 0-130).
- 3 Turning the steering wheel all the way to the left then adjust the left side turning angle by pressing the (+) (-) keys. (This setting the range from 0-130)
- 4 When the steering wheel is in neutral position, you can adjust turning angle of both left and right at the same time by pressing (+) (-) keys.



The Explanation of Each Functions (Function Mode)

Adjusting the Turning Angle of the Steering Servo (Steering Travel)


□ Adjust by GD Lever

When set to Travel Position by GD Lever A, the turning angle can be adjusted assuming the value displayed on the screen as maximum value.

- 1 Change the LCD display from the initial screen to the Function Mode.
- 2 Operate the GD Lever A, LCD will be automatically displayed and the turning angle in both the left and right directions can be adjusted simultaneously.

*The setting range is 0 ~ The


1



Initial Screen

2

b. Displays automatically




a. Operate the GD Lever

c. The turning angle in both the left and right directions can be adjusted simultaneously

! Caution



After the linkage process, make sure the setting does not lock the linkage and cause excessive force to be applied to the servo.
*Excessive force to the servo will result in damage and loss of control.





The Explanation of Each Function (Function Mode)

Adjusting the Steering Response Characteristics (Steering Response)

Can be adjustable into two different characteristics.

☐ Steering Curve

- 1 As shown in the graph, change the angle so that the servo moves quickly in response to the angle the steering wheel is turned,
- 2 Press the Function Key four times from the initial screen, to change to the Steering Response screen.
- 3 Adjust the Steering Curve (setting range +1~+100) by pressing the (+) (-) keys. Positive values yield quicker response.



Advice

This function is effective for cars less sensitive near the neutral position.

The Explanation of Each Function (Function Mode)

Adjusting the Steering Response Characteristics (Steering Response)

□ Steering Speed

This function limits the maximum turning speed of the steering servo.

If wheel operation is slower than the set speed, the operation of the servo is not limited by the setting.



①

Press the Function Key four times from the initial screen, to change to the Steering Response screen.

②

Negative values (-) yield slower turning speed. The setting range is (0~100), with a -100 setting applying maximum limit.

①



Advice

The setting up of the car is of course very important for turning the car smoothly. However rough steering work is just a result in loss of grip in the front tyres. Using the Steering Speed controls the rough steering work and results in more grip. Just like an expert driver you are able to drive in a calm and steady way even though driving with rough steering work.

The Explanation of Each Function (Function Mode)

Adjusting the Throttle Servo Movement (Throttle Travel)

- This function allows you to adjust the amount of servo movement individually for forward and brake. There are three ways to adjust.



Before the linkage adjustment, Set the brake position of the G D Lever B at maximum value.




□ Adjusting by Trim Lever (Direct Set Function)

- Call up the LCD display of initial screen or function mode screen.

Adjusting Forward Direction (F).

- Operating the throttle trim lever whilst the trigger is pulled fully, the LCD screen changes to the forward direction (F) automatically then can be adjusted.



Adjusting Brake Direction (B)

- Operate the throttle trim lever whilst the trigger is pushed fully, the LCD screen changes to the brake direction (B) automatically then can be adjusted.




Operate the trim lever and this setting can range from 0-130.

(reverts back to previous screen in approx. 5 seconds.)

• • • • •

- Press function key 5 times from the initial screen to changes to the Throttle Travel screen.

1. LC D screen indicates forward direction (F) when the throttle trigger is freed.
2. Use the (+) (-) key to adjust turning angle.




- 1 When the trigger is pushed fully, the LCD screen displays brake direction (B).
- 2 Keep this position and use the (+) (-) keys to adjust the maximum brake rate.



At the position of G D lever B, you can set the brake turning angle as maximum value of the Throttle Travel screen. It also allows you to adjust it while you are controlling the model.

LC D screen will display automatically by operating the G D Lever B which then allows the brake turning angle to be set. The setting range is 0~(the value of the brake travel on the screen)



Operate the G D Lever B



After the linkage process, be sure to avoid exerting excessive pressure on the servo when full throttle or brakes are applied.
 *Excessive pressure on the servo will cause damage and loss of control




The Explanations of Each Function (Function Mode)

Throttle Response

In the Throttle Response, the characteristics for forward direction and brake direction can be adjusted in two ways. Throttle Punch or TRC for the forward direction, Brake Punch or ABS for the brake

Throttle Punch

- ① Set up an offset (as shown in the graph) for the effect of trigger operation. In other words, improve the initial effect of throttle response.
- ② Press function key six times from the initial screen to change to the Throttle Response screen. LCD displays forward direction (F) when the trigger is released
- ③ Positive value (+) settings in the screen applies the Throttle Punch feature. The setting can range from 0~+100.



Advice

This function can eliminate the time lag before the clutch engages in a gasoline-powered car or can be used to control the initial application of power in an electric car. The greater the value of the setting the larger movement of the throttle operation at the initial stage.

The Explanation of Each Function (Function Mode)

.....

TRC (Traction Control)



Save power by controlling a delay in the power on direction when the trigger is pulled.

- ① Press Function Key six times from the initial screen to the Throttle Response screen. LCD displays forward direction (F) when freeing the trigger.
- ② Negative value (-) settings applies TRC feature. The setting can range from 1~100. Maximum save is -100.

①



②



Advice

More than necessary rough application of the power will not improve your lap time. Wasting energy result in higher consumption of your nicad batteries. Expert drivers apply the power without wasting the energy and means smooth acceleration. Using the TRC means that you can pull back the throttle quickly.

The Explanation of Each Function (Function Mode)



Brake Punch

Set up and offset (as shown in the graph) for the effect of initial brake operation. In other words, improve the initial effect of brake response.


- ① Press function key six times from the initial screen to change to the Throttle Response screen.
- ② LCD displays brake direction (B) when trigger fully pushed.
- ③ Positive value (+) settings in the screen applies Throttle Punch feature whilst punching the trigger fully.
The setting can range from +1~+100.

※ *If the setting value is too big, the servo simply operates in a fashion similar to a switch.



Brake operation



③ Use (+) (-) keys



② Push fully



Advice


This function can be used to adjust the initial effect of braking, especially for electric cars in that the initial effect of braking is not sufficient in ESC or a loose linkage setup of gasoline-powered cars.

• • • • •

Whilst in braking operation, applying the intermittent movement automatically and performing pumping brake effect.

-
- 1 DOT MATRIX
TH. RESPS
F 0
MULTI CROSS DISPLAY
- 2 Push fully.
- 3 Use (+) (-) keys
- 4 The setting range is -1~100
- 5 Turn on and off when ABS is in operation
- MPUTERIZED
PROPORTIONAL SYSTEM
- TH. RESPS
E - 47
MULTI CROSS DISPLAY
- SETTING PANEL
- FUNC SELECT
- +
2
- DOT MATRIX
TH. RESPS
E 0
MULTI CROSS DISPLAY

When ABS is in operation and the throttle trim is set towards the brake direction and still more the brake travel is setting to a large value, there is a possibility that ABS movement will be left out. If this happens be sure to set the brake trim near to the 0 value.



When more brake power is required or when the car cannot be set up well, this is an extremely effective feature. Firstly using the Brake Travel feature, set up so that maximum braking power can be gained without getting wheel lock. It may require several attempts to find the point at which maximum braking power can be gained without wheel lock.


The Explanation of Each Function (System Mode)

Determine the Direction of Servo and ESC Movement (Reverse)


Use this function when the direction of servo and wheel, trigger operation is in reverse. It will be able to change the direction of servo for Steering (CH1) and Throttle (CH2).

CH3 and the auxiliary channel can set the operation direction in the reverse way.

Use a auxiliary CH position (p27) if you want to determine the direction of servo to the reverse.




- 1 Press and hold down Select Key from the initial screen then press the Function Key, it will change to the System Mode screen.



- 2 Press the Function Key once from the System Mode screen to change to the Reverse screen.



- 3 Use Select Key to change the channel (CH) and the direction can be set by (+) (-) keys.



• • • • •

There are five different ways to select the auxiliary channel (CH3)

It is useful for EG Remote Control Unit.

(P1) and (P2) switches by lever operation.

It is useful for EP trailer gear shift change

It is useful for the mechanism which requires the

- ③ Use Select Key to change the channel (CH) and the movement pattern can be set by (+) (-) keys.





• • • • •

Adjust the each position of the servo in the GD lever selections.

In the Case of 1P Position ~ 4P Position




- 1 By operating the lever in which an auxiliary channel has been set displays each position on LCD.
- 2 Whilst the position is displayed, use (+) (-) keys to adjust.

Diagram illustrating the computerized FM proportional system. The control unit displays "CH3 .Pos" and "P3 +120". The proportional valve is shown with a lever labeled "OPERATE THE LEVER".



Using (+) (-) key to adjust each Position

Operate the lever to the direction you want and the beeper sounds will be changed to the set turning angle.



27



The Explanation of Each Function (System Mode)

.....


Assigning Various Functions to the GD lever (GD Lever Select)

Allows function to be assigned to the GD lever

- ① Press and hold down the Select Key and then press the Function Key to change to the System Mode screen.
- ② Press the Function Key three times from the System Mode screen to change to the GD Lever Select screen.
- ③ Use the Select Key to select the control that a function is to be assigned to GD lever A~C. Then use the (+) (-) keys to select the function to be assigned. The function setting can be repeated so please be careful.



- CH3..... (CH3 Operation)
 CH4..... (CH4 Operation)
 TRAV (Steering Travel position)
(C urrent steering turning angle)
 BRAKE (Bra ke position)
(C urrent brake amount)



Caution




Please use Model Select, GD Select after you fully understand the functions. *Incorrect setting can cause loss of control.

The Explanation of Each Function (System Mode)

Changing the Pumping Cycle of ABS Brake (ABS Cycle)

Two different pumping cycles (intervals) of ABS Brake can be set.

- ① Press and hold down the Select Key and then press the Function Key to change to the System Mode screen.
- ② Press the Function Key 4 times from the System Mode screen to change to the ABS Cycle screen.
- ③ Use the (+) (-) keys to select. For the gasoline-powered car should be set SLOW, and for the electric-powered car should be set Quick.




Advice

For the ESC in the electric-powered car, it will be changed by the braking effect of installed speed controller. Suggest to try both SLOW and QUICK cycle settings. For the gasoline-powered car, the effect of this function will be changed by the speed of throttle servo. SLOW cycle should be better.

To Input, Change and Delete the Names in the Model Memory (Model Name)

For up to six letters or symbols can be stored in each

- ① Press and hold down the Select Key and then press the Function Key to change to the System Mode screen.
- ② Press the Function Key five times from the System Mode screen to change to the Model Name screen.
- ③ Use the Select Key to move the cursor. And the (+) (-) keys to select the characters.



Connecting the Receiver

Warning

Be certain to use only KO Propo genuine FM crystal sets (transmitter and receiver). Never use crystals produced by other companies since such crystals may vary in frequency, which could lead to misoperation or out of control.

Warning

Be sure to connect all equipment correctly. If connections are loosened by vibration, the model may run out of control.

Warning

Do not cut or bundle the aerial wire with other cords. It may result in decreasing the sensitivity of the receiver and may result in the model running out of control.

Caution

Be careful not to reverse the polarity of the transmitter and the receiver. Reverse polarity could damage the units.

Caution


Be sure to use genuine KO Propo products e.g. transmitter, receiver, ESC and other option parts. * We cannot assume any responsibility for the use of other companies products with this unit.

Warning


Be sure to use grommets and be sure that the servo is not touching any metal plates directly. * The vibrations may damage the servo and the model may run out of control.




Connecting the receiver




For an electric-powered car (FET servo + FET



For a gasoline-powered car (6V FET servos)



For a gasoline-powered car (7.2V FET





Notes on Receiver Usage

The Source of Noise and Electromagnetic Induction (Electric-powered car)

- Assume that all areas where large currents are flowing are generating noise!


Locate antenna wires and receivers as far away from the motor, ESC, nicad batteries, and silicone wire as possible. Noise is a type of radio wave, and therefore is radiated (travel through the air) in the same



Metals and carbon can also conduct noise. As a result, you should never closely attach the antenna wire to the plate and carbon chassis.

Distance Between the Receiver and Antenna Holder

- Install the antenna holder as near to the receiver as possible.
The easier it is for the antenna to pick up noise, the



Because this is also part of the antenna, it is easier to pick up nearby noise.


Notes on Receiver Usage

Notes on Installing the Receiver

- The installation position should be as far as possible from the motor, ESC, nicad batteries, silicone wires or other noise sources.

Especially, do not route the silicone wires next to the receiver. (must not be near to the crystal)


FET servo blue wire (7.2V wire) and switches can also generate noise, position them as far away as possible from the receiver



Antenna



The silicon wire passes directly over the receiver.




Do not allow the silicon wires to cross the antenna.

Do not route the wires near the antenna.




Do not position the antenna opening or the crystal near the nicad batteries, motor, or the carbon chassis.

Do not position the receiver or the antenna on top of the motor or the nicad batteries.







When mounting the receiver and antenna on the "upper deck", position them as far away from the nicad batteries and motor as possible.



Mounting the Receiver (Electric-powered car)


- When fixing the receiver in place on the chassis or on the "mech use two pieces of double-sided tape one on top of the other, as that the receiver is cushioned somewhat.



Notes on Installing the Receiver


Notes on Installing the Receiver (Gasoline-powered car)

- Do not secure the receiver on the chassis or the "mechanical deck". Vibrations will cause the receiver to malfunction and may even cause internal damage to the receiver. Either use the bracket (receiver holder) provided with the kit, or else cushion the receiver with a sponge like












Notes on Antenna Installation

- Please follow the instruction as in the illustration below when you mount the antenna holder to the metal or carbon chassis. When using on FRP or carbon hollow antenna on a racing car, etc., do not pass the antenna wire through the pipe, allow it to trail away loosely outside.













LCD Screen Table

LC D Screen	Name of Function	Expla na tion	Refer to:
	Initial screen	Screen display when the power is first turned on.	P13
	Function Mode screen	Displays when entering in the Function Mode.	P13
	Steering Travel	Adjusting overall steering servo turning angle.	P15
	Steering Travel L	Adjusting left steering turning angle.	P12,15
	Steering Travel R	Adjusting right steering turning angle.	P12,15
	Model Select	Changing the model memory.	P14
	Steering Response	Adjusting the steering response characteristics.	P17
	Steering Response (-)	Steering Speed. Steering characteristics of the car become "mild".	P18
	Steering Response (+)	Steering Curve. Steering characteristics of the car become "Quick".	P17

LCD Screen Table

LCD Screen	Name of Function	Explanation	Refer to:
 <p>DOT MATRIX TH. TRAV F100 MULTI CROSS DISPLAY</p>	Throttle Travel (F)	Adjusting turning angle of forward direction.	P19,20
 <p>DOT MATRIX TH. TRAV B100 MULTI CROSS DISPLAY</p>	Throttle Travel (B)	Adjusting turning angle of brake direction.	P19,20
 <p>DOT MATRIX TH. RESPS F + 7 MULTI CROSS DISPLAY</p>	Throttle Response (+)	Throttle Punch. The initial effect of throttle response becomes "Quick"	P21
 <p>DOT MATRIX TH. RESPS F - 44 MULTI CROSS DISPLAY</p>	Throttle Response F (-)	Throttle Traction Control. Save the power on acceleration when the trigger is pulled.	P22
 <p>DOT MATRIX TH. RESPS B + 24 MULTI CROSS DISPLAY</p>	Throttle Response B (+)	Brake Punch. The initial effect of brake response becomes "Quick"	P23
 <p>DOT MATRIX TH. RESPS B - 47 MULTI CROSS DISPLAY</p>	Throttle Response B (-)	ABS (Active Braking System) The intermittent movement will be automatically applied and performing pumping brake effect.	P24
 <p>DOT MATRIX SYSTEM MODE MULTI CROSS DISPLAY</p>	System Mode Screen	Displays when entering in System Mode	P13
 <p>DOT MATRIX REVERSE ST REVE MULTI CROSS DISPLAY</p>	Servo Reverse	Determine the direction of servo	P25
 <p>DOT MATRIX AUX. SEL CH3 -> 3P MULTI CROSS DISPLAY</p>	Auxiliary Channel Select	Select the movement of auxiliary channel.	P26
 <p>DOT MATRIX GD. SELECT GDA -> TRAV MULTI CROSS DISPLAY</p>	GD Lever Select	Assigning various functions to the GD lever.	P28

LCD Screen Table

LCD Screen	Name of Function	Explanation	Refer to:
	ABS Cycle	Changing the pumping cycle of ABS brake.	P29
	Model Name	Input name in Model Memory.	P29
	Travel Position	Displays the current Steering Travel (turning angle).	P16
	Brake Position	Displays the current Brake Travel (turning angle).	P20
	Trim Position (steering)	Displays the current position of Steering Trim.	P10
	Trim Position (throttle)	Displays the current position of Throttle Trim.	P10
	CH3 Position	Displays the current position of CH3.	P27
	CH4 Position	Displays the current position of CH4.	P27
	Low Battery	Battery voltage is dropping.	P9
	Memory Error	Something happening on the CPU memory data.	P9

[illegible]

• • • • •

38

• • • • •

[illegible]

EX-17 **P R E S T O**

LATEST LEADING RADIO CONTROL TECHNOLOGY

MEMO

• • • • •

[illegible]

EX-11 **P R E S T O**

LATEST LEADING RADIO CONTROL TECHNOLOGY

MEMO

• • • • •

[illegible]

EX-11 **P R E S T O**

LATEST LEADING RADIO CONTROL TECHNOLOGY



P R E S T O

• • • • •

Transmitter KT-497FH

Operation method	Wheel and gun grip
Number of channels	4 Channels
Transmission frequency	Any band by changing crystal within the frequency range
Modulation method	FM-PPM
Neutral pulse	1.5mSec
Memory	EEPROM
Supply voltage	9.6V (Nicad, Hydropack) or 12V (8x AA size dry cell)
Current consumption	Less 250mA

Receiver KR-297FZ

Reception method	FM-PPM
Number of channels	2 Channels
Reception frequency	Any band by changing crystal within the frequency range
IF frequency	455 KHz
Supply voltage	3.5~6.5V
Dimensions	36.6 x 26 x 15.5 mm (excluding protrusions)

KO PROPO®

LATEST LEADING RADIO CONTROL TECHNOLOGY

Manufactured By

KONDO KAGAKU CO.,LTD
4-17-7 Higashi Nippori, Arakawa-ku
Tokyo, 116 Japan.
Tel: +81-3-3807-7751 Fax: +81-3-3807-8155

EX-11
P R E S T O

KONDO KAGAKU Co.,Ltd.