

Start Guide

This software is designed for basic operation of the ARC System.
KO Propo has no responsibility for technical support of this software, directly or indirectly occurred damage has no responsibility as a result of using this software.
However the copy right and other legal rights reserved to KO Propo.

What is ARC Operation?

ARC Operation is the software included with the ARC System.
This software is suitable for lap count test and pretest for proper race meetings.
Please read this manual carefully in order to use this software.

Operation system: Microsoft Windows 95 or above.

Please refer to your operation system for more details.

Requires one **RS-232C port** for connection with PC and ARC.

Display: 800x600 256 colour.

Installation: Copy files in floppy disk to desired directly i.e. C:\ARC

Start: Double click on ARC12B.exe

It is recommended to make a short cut in desk top.

After opening the programme display shown as follows.

Pos	No	LastLap	BestLap	RunTime	LAP	HitX	HitN	Freq	Target	LAP	No	Time	Hit
1								26.875	1	1			
2								26.885	2	2			
3								27.025	3	3			
4								27.045	4	4			
5								26.075	5	5			
6								27.085	6	6			
7								27.125	7	7			
8								27.145	8	8			
9								27.175	9	9			
10								27.195	10	10			
11								27.225	11	11			
12								27.255	12	12			
13									13	13			
14									14	14			
15									15	15			
16									16	16			
17									17	17			
18									18	18			
19									19	19			
20									20	20			

KO PROPO Name

Mode: ☒ ARC ☐ Fix No

COM: COM1 Delay: 259 Lap Limit: BT43 StartStyle: NO T-Limit(M): NO

PRINT Save Load Graph SET IN U

Start Stop

The company name or other brand name in this manual is protected by law.
ARC System is PATP by KO Propo.